






















Which direct acting room heater? Our guide to our full range.

AREA	SUITABLE RANGES				KEY									
 BATH OR SHOWER ROOM / WC	 BHE PLUS	 CK 20 TREND LCD	 CK 20 PREMIUM	<ul style="list-style-type: none">➤ BHE Plus** - Lot 20 compliant towel-rail heater.➤ CK 20 Premium* - Where you want a premium rapid fan heater with silent mode.➤ CK 20 Trend LCD** - Fast response fan heater when you want an affordable option that will heat an area with maximum speed.➤ CNS-U Plus LCD UK* - A next level panel heater with enhanced aesthetics. & simple LCD controls.➤ CNS Connect* - Wi-fi enabled for simple app control.➤ CNS NC* - Has time and temperature settings controlled by a landlord control with a timed boost option for tenants.➤ CNS Move* - 2kW portable heater with safety cut out if the heater is knocked over.➤ CON Premium* - Premium build quality and aesthetics.➤ CND** - The added luxury of a radiant element of heat (can be particularly valuable for comfort in older properties where surfaces can be cold to touch).➤ IW 120*** - Infrared quartz radiant heater for indoors and sheltered outdoor areas. <p><i>*Splashproof IP 24, protection class I, **Splashproof IP 24, protection class II, ***Splashproof IP X4, protection class I.</i></p> <p>What size heater do I need? Sizing heaters depends on the thermal values of the room and other factors such as ceiling height, air change rates, the local external temperatures and the desired internal temperatures and response times. We recommend you contact us with details of room sizes and U values or age-of-building information once you have selected the type of heater desired.</p> <p>To get a quick estimate of the size convector or fan heater you need*:</p> <ol style="list-style-type: none">1. Measure the size of your room in square metres2. Select the required watts per square metre based on the age of your building below3. Multiply the final figure by 1.3 to get a rough estimate of what wattage you require <p><i>*Do not apply this method to storage heaters.</i></p> <table><tr><th>AGE OF BUILDING</th><th>WATTS PER SQM</th></tr><tr><td>2006 onward</td><td>45</td></tr><tr><td>2002-2005</td><td>48</td></tr><tr><td>1995-2001</td><td>64</td></tr><tr><td>Before 1995</td><td>135</td></tr></table> <p>For more detail on the wider range go to: www.stiebel-eltron.co.uk/heaters</p>	AGE OF BUILDING	WATTS PER SQM	2006 onward	45	2002-2005	48	1995-2001	64	Before 1995	135
AGE OF BUILDING	WATTS PER SQM													
2006 onward	45													
2002-2005	48													
1995-2001	64													
Before 1995	135													
 LIVING	 CNS-U PLUS LCD UK	 CON PREMIUM	 CND	 CNS CONNECT										
 BEDROOM	 CNS-U PLUS LCD UK	 CON PREMIUM	 CND	 CNS CONNECT										
 WHERE LANDLORD PAYS THE BILL	 CNS NC													
 OCCASIONAL USE / PLANT ROOMS	 CK 20 PREMIUM	 CK 20 TREND LCD	 CNS MOVE	 IW 120										